


PVM Code B

ENGINEERING
TOMORROW



Service Guide

PVM code B Service Guide



[https://powersource.danfoss.com/
products/pumps/industrial-pumps/
medium-duty-open-circuit-piston-pumps](https://powersource.danfoss.com/products/pumps/industrial-pumps/medium-duty-open-circuit-piston-pumps)

Contents

1. Overview	4
2. Safety Precautions.....	4
3. Installation	5
3.1. Installation of Pump - Motor Unit	5
3.1.1. Hosting of the Hydraulic Pump	5
3.1.2. Installation Of the Bell Housing Coupling	5
3.1.3. Pump Installation	5
3.2. Tandem pump series installation	6
3.3. Pipeline Installation	7
4. Hydraulic Fluids	8
4.1. Fluid Cleanliness	8
5. Start-Up Procedure	8
6. Commissioning guidelines	9
6.1. Pressure Compensator – Code A	9
6.1.1. Pressure compensator - High pressure type	10
6.1.2. Pressure compensator - Low Pressure type	10
6.2. Pressure and Flow Compensator – Code B or C	10
6.2.1. Pressure Compensator high pressure + Flow Compensator high pressure	13
6.2.2. Pressure Compensator low pressure + Flow Compensator high pressure	13
6.2.3. Pressure Compensator high pressure + Flow Compensator low pressure	13
6.2.4. Pressure Compensator low pressure + Flow Compensator low pressure	13
6.2.5. Pressure Compensator high pressure + Flow Compensator high pressure	13
6.2.6. Pressure Compensator low pressure + Flow Compensator high pressure	14
6.2.7. Pressure Compensator high pressure + Flow Compensator low pressure	14
6.2.8. Pressure Compensator low pressure + Flow Compensator low pressure	14
6.3. Power Control/Torque Limiter	14
6.4. Industrial Control	17
6.5. Maximum Displacement Adjustment Stop	17
7. Maintenance Guidelines	18
7.1. Disassembly - Pressure compensator (PVM 18 cc to 50 cc)	18
7.2. Assembly – Pressure compensator (PVM 18 cc to 50 cc)	18
7.3. Disassembly - Pressure and Flow compensator (PVM 18 cc to 50 cc)	20
7.4. Assembly - Pressure and Flow compensator (PVM 18 cc to 50 cc)	20
7.5. Disassembly - Pressure compensator (PVM 57 cc to 141 cc)	22
7.6. Assembly - Pressure compensator (PVM 57 cc to 141 cc)	23
7.7. Disassembly – Pressure and Flow Compensator (PVM 57 cc to 141 cc)	25
7.8. Assembly – Pressure and Flow Compensator (PVM 57 cc to 141 cc)	25
7.9. Disassembly – Industrial Controller (PVM 57 cc to 141 cc)	28
7.10. Assembly – Industrial controller (PVM 57 cc to 141 cc)	28
7.11. Disassembly – Torque Controller/Power Limiter (PVM 57 cc to 141 cc)	31

7.12. Assembly – Torque Controller/Power Limiter (PVM 57 cc to 141 cc)	31
7.13. Disassembly – Auxiliary Mounting Flange (PVM 45 cc to 141 cc)	32
7.14. Assembly – Auxiliary Mounting Flange (PVM 45 cc to 141 cc)	32
7.15. Disassembly - Shaft Seal (PVM 10 cc to 141 cc)	34
7.16. Assembly – Shaft Seal (PVM 10 cc to 141 cc)	34
7.17. Pump Seal Kits	35
7.17.1. Pump seal Kit 10-13-18-20 cc	35
7.17.2. Pump seal Kit 45-50 cc	36
7.17.3. Pump seal Kit 57-63 cc	37
7.17.4. Pump seal Kit 74-81 cc	38
7.17.5. Pump seal Kit 98-106 cc	39
7.17.6. Pump seal Kit 131-141 cc	40
8. Troubleshooting for common faults	41
8.1. Excessive noise and/or vibration	41
8.2. Actuator response is sluggish	41
8.3. System operating hot.....	41
8.4. Low pump output flow.....	42
8.5. Pressure or flow instability	42
8.6 System pressure not reaching PC setting	43
8.7 High inlet vacuum.....	43

1. Overview

This manual contains information about the installation, maintenance, and simple repair of the PVM series open-type axial piston pumps. It covers the instructions for the pump and its various sub-assemblies, troubleshooting information, and simple repair procedures. Please follow the procedures in this manual for the installation, maintenance, and simple repair of the PVM series open-type axial piston pumps to avoid affecting the product warranty.

Simple maintenance can only be carried out after the pump has been removed from the machine. Before any maintenance or repair work, thoroughly clean the pump. Since dust and contamination are the most detrimental factors for any hydraulic equipment, please strictly comply with the cleanliness requirements.

Especially when replacing the system filters or disassembling and assembling the hydraulic pipes, make sure that the cleanliness meets the standards!

2. Safety Precautions

Always consider safety precautions before beginning a service procedure. Protect yourself and others from injury. Take the following general precautions whenever servicing a hydraulic system.

Unintended machine movement



WARNING

Unintended movement of the machine or mechanism may cause injury to the technician or by standers. To protect against unintended movement, secure the machine or disable / disconnect the mechanism while servicing.

Flammable cleaning solvents



WARNING

Some cleaning solvents are flammable. To avoid possible fire, do not use cleaning solvents in an area where a source of ignition may be present.

Fluid under pressure



WARNING

Escaping hydraulic fluid under pressure can have sufficient force to penetrate your skin causing serious injury and/or infection. This fluid may also be hot enough to cause burns. Use caution when dealing with hydraulic fluid under pressure. Relieve pressure in the system before removing hoses, fittings, gauges, or components. Never use your hand or any other body part to check for leaks in a pressurized line. Seek medical attention immediately if you are cut by hydraulic fluid.

Personal safety



WARNING

Protect yourself from injury. Use proper safety equipment, including safety glasses, at all times.

3. Installation

Before installation, check to ensure that all shipped components are complete, free from any damage, and not externally contaminated. Protect them properly to prevent the intrusion of contaminants. It is recommended to thoroughly clean the equipment with hydraulic oil before installation to remove any possible corrosive substances that may be present.

3.1. Installation of Pump - Motor Unit

To ensure the normal operation of the oil pump and extend its service life, the input shaft of the hydraulic pump is strictly prohibited from bearing additional radial and axial loads. The Danfoss hydraulic pump should be connected to the output shaft of the prime mover by means of a bell housing and an elastic coupling, and the two shafts need to be accurately aligned. The coaxial error of the axes should not exceed 0.08mm, and the angular error should not exceed 0.5°.

Before assembly, it is necessary to check the relevant dimensions of the bell housing and coupling to ensure that the design and manufacturing meet the assembly requirements of the pump-motor unit.

3.1.1. Hoisting Of the Hydraulic Pump

When hoisting the hydraulic pump, the lifting device should be hooked on the base or the lifting rings of the pump body. It is strictly prohibited to hoist the main shaft of the oil pump! Knocking or hitting the main shaft and the sealing surfaces of the oil inlet and outlet is strictly prohibited.

3.1.2. Installation Of the Bell Housing Coupling

Install the key block on the pump shaft and loosen the set screws inside the coupling. Use a copper rod to gently and evenly tap the coupling on the pump to install the coupling in the proper position. (Note to control the tapping force. Heavy blows are strictly prohibited!).

Install the key block on the motor shaft. Use a copper rod to gently and evenly tap the coupling to install the coupling in the appropriate position. (Pay attention to controlling the tapping force. Heavy tapping is strictly prohibited!)


When installing the motor, bell housing and pump, make selections according to the actual situation to ensure the reliability and convenience of the connection.

After the installation, check the coaxiality and perpendicularity between the main shaft of the motor and the positioning boss of the bell housing. Check the clearance of the coupling to ensure that it is between 3 and 5 millimetres.

3.1.3. Pump Installation

The pump can be installed horizontally or vertically (with the shaft end facing upwards). Rigid connections between the pump and the oil tank cover or tank body, as well as between the pump and the oil suction steel pipe and the oil discharge steel pipe should be avoided, to prevent the entire system from being excited by the vibration of the pump.

Vertical installation inside the reservoir



Caption		
$h_{ES\ min}$	Minimum high of the bow above the pump to ensure that the pump case is always filled up completely	50mm
h_{min}	Minimum required immersion depth	200mm
$h_{b\ min}$	Minimum distance of the end of the suction line to the reservoir bottom	100mm
S	suction port	-
K	drain port K	-
K_1	drain port K_1	-
d_{min}	Minimum distance between the end of the suction line and the end of the drain line	300mm
SB	Baffle (baffle plate), recommended for each reservoir. In case of no baffle it is necessary to maintain d_{min}	-
F	filling and venting port	-

3.2 Tandem pump series installation

To avoid excessive stress on the pump flange, additional pump supports may be required for tandem configurations.

In industrial applications, additional supports are generally not required for combinations of two pumps of the same specification. However, for combinations of more than two pumps stacked together, supports must be provided.

3.3. Pipeline Installation

- Carry out pipeline configuration according to the provisions of the operation manual. The connecting pipes of the hydraulic pump include the inlet and outlet connecting pipes and the leakage oil pipe.
- Remove the plastic protective cover on the pump oil port before installation.
- The oil suction port is preferably located at the bottom or side of the pump. The maximum flow velocity of the oil suction port should not exceed $v = 1.0 \text{ m/s}$. Even during the pressure compensation period, the pressure at the suction port should not be lower than 0.8 bar (absolute pressure).
- The oil suction pipe must suck in clean, cooled, filtered oil without air bubbles.
- The oil suction port should be monitored by a proximity switch or a similar device. When the valve is closed, the prime mover should be prevented from starting.
- Install a short oil suction pipe with a 45° bevelled port into the oil tank.
- Use the oil drain port at the highest position on the pump body. It is recommended that the length of the housing drain oil pipe does not exceed 2 meters. If the length exceeds 2 meters, the pipeline size needs to be increased to reduce the restriction.
- The housing drain oil pipeline must never be combined with the return oil pipeline/drain oil pipeline. Always ensure that the housing is filled with oil. In the case of oil shortage, the pump will fail prematurely.
- The maximum allowable housing pressure is 2 bar. (Parameter requirement for the oil drain pipeline.)
- If bearing flushing is required, please refer to the figure 2 for pipeline configuration:




Figure 2

4. Hydraulic Fluids

Fluid	Recommended Operating Viscosity Range	Maximum Viscosity at Startup	Minimum Viscosity @ Max. Intermittent Temperature of 104°C (220°F)
	cSt (SUS)	cSt (SUS)	cSt (SUS)
Use antiwear hydraulic oil, or automotive type crankcase oil (designations SC, SD, SE, or SF) per SAE J183 FEB80	16 to 40 (83 to 187)	1000 (4550)	10 (90)

Note: For detailed usage instructions of water-glycol (HFC) hydraulic oil, please refer to the HFC Usage Manual of PVM Pump.

4.1 Fluid Cleanliness

Any form of contamination is a great enemy to any hydraulic component, and it remains the primary cause of component failures. Therefore, for the components that come into contact with hydraulic oil, extreme care must be taken during all operation and management processes to ensure their cleanliness. All oil ports of pumps and other components must be plugged before hard pipes or hoses are installed. It is advisable to carry out the assembly in a dry and dust-free environment. Only use appropriate tools for assembly. The recommended cleanliness level to ensure the maximum service life and reliability of the components is level 18/16/13, which is in compliance with ISO 4406 (NAS7).

5. Start-Up Procedure

- To ensure the normal operation of the oil pump, make sure that the coupling and the motor are correctly connected, and pay attention to the direction of rotation, mechanical connection, etc.
- Confirm that all the plastic plugs on the oil ports have been removed and ensure that the pipeline is unobstructed and correctly connected.
- Conduct a comprehensive inspection of the installation of the hydraulic pump. Check the installation of each oil port to see if there are any issues such as omitted installations or misconnected oil pipes. Pay special attention to ensuring that the oil drain pipeline is unobstructed.
- Manually rotate the shaft of the hydraulic pump as much as possible so that all components of the pump can be lubricated during the trial operation, and the air bubbles inside the pump can also be reduced.
- Check the oil level in the oil tank.
- The cleanliness of the oil should meet the requirements.
- The housing must be filled with oil before startup.

6. Commissioning guidelines

6.1 Pressure Compensator – Code A

After loosening the locknut, turn the pressure adjusting rod clockwise to increase the pressure, and turn the pressure adjusting rod counterclockwise to decrease the pressure. Adjust it to the required pressure and then tighten the locknut (14-20 Nm).




Figure 3




Figure 4




Figure 5

Two types of pressure compensator are offered for sizes from 10 cc to 141 cc

6.1.1 Pressure compensator - High pressure type

Pressure adjustment range 140 bar – 315 bar.

Theoretical pressure regulation coefficient 57 bar/turn.

Ordering code	Pump displacement [cc/rev]													
	10	13	18	20	45	50	57	63	74	81	98	106	131	141
9901512-002	•	•	•	•	•	•								
9901517-002									•	•			•	•
9901517-021											•	•		
9901517-041							•	•						

6.1.2 Pressure compensator - Low Pressure type

Pressure adjustment range 35bar – 130 bar.

Theoretical pressure regulation coefficient 27 bar/turn.

Ordering code	Pump displacement [cc/rev]													
	10	13	18	20	45	50	57	63	74	81	98	106	131	141
9901512-003	•	•	•	•	•	•								
9901517-003									•	•			•	•
9901517-022											•	•		
9901517-042							•	•						

6.2 Pressure and Flow Compensator – Code B or C

After loosening the lock nut, turn the pressure regulating rod clockwise to increase the pressure, and turn the pressure regulating rod counterclockwise to decrease the pressure. Adjust it to the required pressure and then tighten the lock nut.

Pump size [cc/r]	10cc – 50 cc	57cc – 141 cc
Lock Nut Tightening torque	32 - 38 Nm	14 -20 Nm




Figure 6




Figure 7




Figure 8

In addition to the 2 types of Pressure compensators, there are 2 types of Flow compensators.

Flow compensator – High pressure type


- Pressure adjustment range 21 bar – 41 bar.
- Theoretical pressure regulation coefficient 16 bar/turn

Flow compensator – Low pressure type

- Pressure adjustment range 10 bar – 20 bar.
- Theoretical pressure regulation coefficient 10 bar/turn

The Pressure and Flow Compensator – also identified as Load Sensing compensator – either has the bleed down orifice (Code B) or is without the bleed down orifice (Code C)

This leads to 8 different varieties of Pressure and Flow compensators



6.2.1 Pressure Compensator high pressure + Flow Compensator high pressure

	Pump displacement [cc/rev]													
Ordering code	10	13	18	20	45	50	57	63	74	81	98	106	131	141
9901512-005	•	•	•	•	•	•								
9901517-004									•	•			•	•
9901517-023											•	•		
9901517-043							•	•						

6.2.2 Pressure Compensator low pressure + Flow Compensator high pressure

	Pump displacement [cc/rev]													
Ordering code	10	13	18	20	45	50	57	63	74	81	98	106	131	141
9901512-009	•	•	•	•	•	•								
9901517-006									•	•			•	•
9901517-025											•	•		
9901517-045							•	•						

6.2.3 Pressure Compensator high pressure + Flow Compensator low pressure

	Pump displacement [cc/rev]													
Ordering code	10	13	18	20	45	50	57	63	74	81	98	106	131	141
9901512-007	•	•	•	•	•	•								
9901517-005									•	•			•	•
9901517-024											•	•		
9901517-044							•	•						

6.2.4 Pressure Compensator low pressure + Flow Compensator low pressure

	Pump displacement [cc/rev]													
Ordering code	10	13	18	20	45	50	57	63	74	81	98	106	131	141
9901512-011	•	•	•	•	•	•								
9901517-007									•	•			•	•
9901517-026											•	•		
9901517-046							•	•						

6.2.5 Pressure Compensator high pressure + Flow Compensator high pressure

	Pump displacement [cc/rev]													
Ordering code	10	13	18	20	45	50	57	63	74	81	98	106	131	141
9901512-004	•	•	•	•	•	•								
9901517-008									•	•			•	•
9901517-027											•	•		
9901517-047							•	•						

6.2.6 Pressure Compensator low pressure + Flow Compensator high pressure

	Pump displacement [cc/rev]													
Ordering code	10	13	18	20	45	50	57	63	74	81	98	106	131	141
9901512-008	•	•	•	•	•	•								
9901517-010									•	•			•	•
9901517-029											•	•		
9901517-049							•	•						

6.2.7 Pressure Compensator high pressure + Flow Compensator low pressure

	Pump displacement [cc/rev]													
Ordering code	10	13	18	20	45	50	57	63	74	81	98	106	131	141
9901512-006	•	•	•	•	•	•								
9901517-009									•	•			•	•
9901517-028											•	•		
9901517-048							•	•						

6.2.8 Pressure Compensator low pressure + Flow Compensator low pressure

	Pump displacement [cc/rev]													
Ordering code	10	13	18	20	45	50	57	63	74	81	98	106	131	141
9901512-010	•	•	•	•	•	•								
9901517-011									•	•			•	•
9901517-030											•	•		
9901517-050							•	•						

6.3 Power Control/Torque Limiter

The Power Control limits the maximum torque output by the piston pump by reducing the displacement as pressure increases hence limiting the power rating at a given speed.

After loosening the lock nut, turn the pressure regulating rod clockwise to increase the power, and turn the pressure regulating rod counterclockwise to decrease the power. Adjust it to the required power and then tighten the lock nut (14 - 20 Nm).

Ensure that the damping with a diameter of $\Phi 0.7$ exists in the tee joint on the load sensing valve.

If the load sensing function is used, the feedback oil circuit of the load sensing can be directly connected to this tee joint.




Figure 9

Item No.	Part description	Torque control Kit	Torque control pipeline kit
118	PVM HP Control S/A	●	
119	Adapter ORS Straight thread run tee	●	●
120	Plug-Orifice	●	●
121	Adapter/ ORS 90 Deg straight thread elbow	●	●
122	Tube Assembly	●	●
126	O-Ring Side (ORS) 90 Deg Swivel elbow	●	●

If the load sensing function is not used, the high - pressure oil at the P - port needs to be connected to this tee joint. Do not tighten the screw of the load sensing valve.

The dimension "X" shown below should be checked and controlled after tightening the lock nut of the cartridge valve. Acceptable dimension for each size is mentioned in the table.

Pump Size	Acceptable value of X
[cc/rev]	[mm]
57	58.5±0.4
63	58.5±0.4
74	60.5±0.4
81	60.5±0.4
98	57.5±0.4
106	57.5±0.4
131	60±0.4
141	60±0.4




Figure 10

The power limitation value in kW at 1500 rpm can be set by setting the height “S” of the adjusting screw shown below. Rotating adjustment screw clockwise increases the power setting while rotating it anticlockwise reduces it. After adjustment as required ensure that the locknut is tightened properly.

Ordering codes for the Torque controller

	Pump displacement [cc/rev]													
Ordering code	10	13	18	20	45	50	57	63	74	81	98	106	131	141
9901520-001													•	•
9901520-002											•	•		
9901520-003									•	•				
9901520-004							•	•						

Ordering code for torque control pipeline kit

	Pump displacement [cc/rev]													
Ordering code	10	13	18	20	45	50	57	63	74	81	98	106	131	141
9901538-000													•	•
9901541-000									•	•				
9901542-000											•	•		
9901543-000							•	•						

Ordering code for torque control pipeline kit

	Pump displacement [cc/rev]													
Ordering code	10	13	18	20	45	50	57	63	74	81	98	106	131	141
9901537-000							•	•	•	•	•	•	•	•

6.4 Industrial Control

This controller is offered only with the sizes from 57 to 141 cc/rev and is intended to be used when multiple, remote or electronically controlled compensation settings, with (controlled code E) or without load sensing (Controlled code F) is desired. The controller has a NFPA-D03/ISO 4401-03 interface on its top for the various control strategies.




Figure 11

Ordering code for Industrial Controller (Controller code E)

	Pump displacement [cc/rev]													
Ordering code	10	13	18	20	45	50	57	63	74	81	98	106	131	141
9901517-012							●	●	●	●	●	●	●	●

Ordering code for Industrial Controller (Controller code F)

	Pump displacement [cc/rev]													
Ordering code	10	13	18	20	45	50	57	63	74	81	98	106	131	141
9901517-013							●	●	●	●	●	●	●	●

6.5 Maximum Displacement Adjustment Stop

Displacement adjustment can only be carried out after the pump is stopped.

After loosening the lock nut, turn the pressure regulating rod clockwise to increase the displacement, and turn the pressure regulating rod counterclockwise to decrease the displacement. Adjust it to the required displacement and then tighten the lock nut.

The minimum adjustable displacement is 50% of the full displacement.

The reference value of displacement per turn is shown in the following table:

Pump size [cc/rec]	10/13/18/20	45/50	57/63	74/81	98/106	131/141
Size reduction per turn [cc/rev]	1.1	2.1	2.98	3.5	4.5	5.7
Lock nut tightening torque	M8: 10-24 Nm			M10: 24-30 Nm		

7. Maintenance Guidelines

7.1 Disassembly - Pressure compensator (PVM 18 cc to 50 cc)

1. Remove the four screws fastening the compensator housing to the end cap (Figure 12②).
2. Remove the compensator and take out the three O-rings (Figure 12③④).
3. Remove the screw plug (Figure 11⑨⑩).
4. Remove the pressure valve core (Figure 11⑧).
5. Remove the assembly of the screw plug (Figure 11⑤), the adjusting rod (Figure 11④) and the lock nut (Figure 11⑧).
6. Remove the pressure compensator spring (Figure 11③) and the two spring seats (Figure 11②).

7.2 Assembly – Pressure compensator (PVM 18 cc to 50 cc)

1. Install the pressure valve core (Figure 11⑧).
2. Install the screw plug (Figure 11⑨⑩) and tighten it with a torque ranging from 9.8 to 10.2 Nm.
3. Install the pressure compensator spring (Figure 11③) and the two spring seats (Figure 11②).
4. Install the assembly of the screw plug (Figure 11⑤), the adjusting rod (Figure 11④) and the lock nut (Figure 11⑧), and tighten the screw plug with a torque of 75 - 83 Nm.
5. Install three O-rings (Figure 12③④). The one in the middle is larger, and the ones at ends are smaller.
6. Fasten the compensator housing to the end cover with four screws (Figure 12②) and tighten them with a torque of 7.4 - 9 Nm. When tightening, use a crisscross pattern and re-tighten the first screw.




Figure 12




Figure 13




Figure 14

Ordering code for Pressure Compensator Seal Kit (18-50 cc) (Figure 13)

Ordering code	Pump displacement [cc/rev]													
	10	13	18	20	45	50	57	63	74	81	98	106	131	141
9901549-000	•	•	•	•	•	•								

7.3 Disassembly - Pressure and Flow compensator (PVM 18 cc to 50 cc)

1. Remove the four screws that fix the compensator housing to the end cap (Figure 14 ②).
2. Remove the compensator and take out the three O-rings (Figure 14 ③④).
3. Remove the screw plug (Figure 15 ⑤).
4. Take out the pressure compensator valve spool (Figure 15 ⑩) and the flow compensator valve spool (Figure 15 ④).
5. Remove the four screws at the adjusting end of the compensator (Figure 15 ⑫).
6. Remove the assembly of the adjusting rod (Figure 20 ⑦), the lock nut (Figure 15 ⑧), the retaining ring (Figure 15 ⑨), the O-ring (Figure 15 ⑩) and the plate (Figure 15 ⑪).
7. Take out the pressure compensator spring (Figure 20 ⑥) the flow compensator spring (Figure 15 ③) and the spring seat (Figure 15 ②).
8. Remove the side screw plug (Figure 20 ⑭) and the damping plug (Figure 20 ⑬⑭).

7.4 Assembly - Pressure and Flow compensator (PVM 18 cc to 50 cc)

1. Install the pressure compensator valve spool (Figure 15 ⑩) and the flow compensator valve spool (Figure 15 ④). The rounded ends should face inward. The pressure compensator valve spool has fewer ring grooves and is shorter, while the flow compensator valve spool has more ring grooves and is longer.
2. Install the screw plug (Figure 15 ⑤) and tighten it with a torque of 5.7 - 6.9 Nm.
3. Install the pressure compensator spring (Figure 15 ⑥), the flow compensator spring (Figure 15 ③) and the spring seat (Figure 15 ②).
4. Install the assembly of the adjusting rod (Figure 15 ⑦), the lock nut (Figure 15 ⑧), the retaining ring (Figure 15 ⑨), the O-ring (Figure 15 ⑩) and the plate (Figure 15 ⑪).
5. Install the four screws at the adjusting end (Figure 15 ⑫) and tighten them with a torque of 14.4 - 17.6 Nm.
6. Install the side screw plug (Figure 15 ⑭) and tighten it with a torque of 13.5 - 16.3 Nm. Install the damping plug (Figure 15 ⑬⑭) and tighten it with a torque of 4 - 6 Nm.
7. Install the three O-rings (Figure 14 ③④). The one in the middle is larger, and the ones at both ends are smaller.
8. Fasten the compensator housing to the end cover with four screws (Figure 14 ②), and tighten them with a torque of 7.4 - 9 Nm. When tightening, use a cross - crisscross pattern and re - tighten the first screw.




Figure 15




Figure 16




Figure 17

Ordering code for Pressure and Flow Compensator Seal Kit (18-50 cc) (Figure 16)

Ordering code	Pump displacement [cc/rev]													
	10	13	18	20	45	50	57	63	74	81	98	106	131	141
9901550-000	●	●	●	●	●	●								

7.5 Disassembly - Pressure compensator (PVM 57 cc to 141 cc)

- 1. Remove the four screws that fix the compensator housing to the end cap (Figure 17, item ②).
- 2. Dismantle the compensator and remove the three O - rings (Figure 17, item ③).
- 3. Dismantle the screw plug assembly (Figure 18, items ⑨ ⑩).
- 4. Remove the pressure valve core (Figure 18, item ②).
- 5. Remove the assembly of the screw plug assembly (Figure 18, items ⑥ and ⑤), the adjusting rod (Figure 18, item ⑦) and the lock nut (Figure 18, item ⑧).
- 6. Take out the pressure spring (Figure 18, item ④) and the two spring seats (Figure 18, item ③).

7.6 Assembly - Pressure compensator (PVM 57 cc to 141 cc)

1. Insert the pressure valve core (Figure 18, item ②).
2. Install the screw plug assembly (Figure 18, ⑨ ⑩), and tighten it with a torque of 29-32 Nm.
3. Install the pressure spring (Figure 18, ④) and two spring seats (Figure 18, ③).
4. Install the assembly of the screw plug assembly (Figure 18, ⑥ ⑤), the adjusting rod (Figure 18, ⑦) and the locknut (Figure 18, ⑧), and tighten the screw plug with a torque of 97-106 Nm.
5. Install three O-rings (Figure 17, ③).
6. Fix the compensator housing to the end cover using four screws (Figure 17, ②), and tighten them with a torque of 31-37 Nm. When tightening, do it in a crisscross pattern and retighten the first screw.




Figure 18




Figure 19




Figure 20

Ordering code for Pressure Compensator Seal Kit (57-141 cc) (Figure 19)

	Pump displacement [cc/rev]													
Ordering code	10	13	18	20	45	50	57	63	74	81	98	106	131	141
9901545-000							●	●	●	●	●	●	●	●

7.7 Disassembly – Pressure and Flow Compensator (PVM 57 cc to 141 cc)

1. Remove the 4 screws that fix the compensator housing to the end cap (Figure 20, item ②).
2. Remove the compensator and take out the three O-rings (Figure 20, item ③).
3. Remove the two screw plugs (Figure 21, item ⑰).
4. Take out the pressure compensator valve core (Figure 21, item ②) and the flow compensator valve core (Figure 21, item ⑮).
5. Remove the screw plug assembly (Figure 21, items ⑨ and ⑩), and take out the flow compensator spring seat (Figure 21, item ⑪), the flow compensator spring (Figure 21, item ⑫), and the limit pin (Figure 21, item ⑬).
6. Remove the screw plug assembly (Figure 21, items ⑥ and ⑤), and take out the pressure compensator spring seat (Figure 21, item ④) and the pressure compensator spring (Figure 21, item ③).
7. Remove the upper screw plug (Figure 21, item ⑭) and the damping plug (Figure 21, item ⑱).

7.8 Assembly – Pressure and Flow Compensator (PVM 57 cc to 141 cc)

1. Install the pressure compensator valve core (Figure 21, item ②) and the flow compensator valve core (Figure 21, item ⑮), with the round heads facing inward. The pressure compensator valve core has more ring grooves and is longer, while the flow compensator valve core has fewer ring grooves and is shorter.
2. Install two screw plugs (Figure 21, item ⑰) and tighten them with a torque of 29 - 32 Nm.
3. Insert the flow compensator spring seat (Figure 21, item ⑪), the flow compensator spring (Figure 21, item ⑫), and the limit pin (Figure 21, item ⑬).
4. Install the screw plug assembly (Figure 21, items ⑨ and ⑩), and tighten it with a torque of 75 - 83 Nm.
5. Insert the pressure compensator spring seat (Figure 21, item ④) and the pressure compensator spring (Figure 21, item ③).
6. Install the screw plug assembly (Figure 21, items ⑥ and ⑤), and tighten it with a torque of 97 - 106 Nm.
7. Install the upper screw plug (Figure 21, item ⑭) and tighten it with a torque of 29 - 32 Nm.
8. Install the damping plug (Figure 21, item ⑱) and tighten it with a torque of 1.7 - 2.3 Nm.
9. Install three O - rings (Figure 20, item ③).
10. Use four screws (Figure 20, item ②) to fasten the compensator housing onto the end cap and tighten them with a torque of 31 - 37 Nm. When tightening, do it in a crisscross pattern and re-tighten the first screw.




Figure 21




Figure 22




Figure 23

Ordering code for Pressure and Flow Compensator Seal Kit (57-141 cc)

Ordering code	Pump displacement [cc/rev]												
	10	13	18	20	45	50	57	63	74	81	98	106	131
9901546-000							•	•	•	•	•	•	•

7.9 Disassembly – Industrial Controller (PVM 57 cc to 141 cc)

1. Remove the four screws (Figure 23, ②78) that fix the compensator housing to the end cover.
2. Remove the compensator and take out the three O-rings (Figure 23, ③85).
3. Remove the screw plug assembly (Figure 24, ①⑧).
4. Take out the compensator valve core (Figure 24, ②).
5. Remove the screw plug assembly (Figure 24, ⑤⑥⑦⑧), and take out the spring seat (Figure 24, ③), the compensator spring (Figure 24, ④) and the limit pin (Figure 24, ⑨).
6. Remove the screw plug assembly (Figure 24, ①⑥⑧), and remove the damping plug (Figure 24, ⑫).
7. Remove the screw plug assembly (Figure 24, ⑭⑮), and remove the damping plug (Figure 24, ⑬).
8. Remove the screw plug assembly (Figure 24, ⑩⑪).

7.10 Assembly – Industrial controller (PVM 57 cc to 141 cc)

1. Install the compensator valve core (Figure 24, ②).
2. Install the screw plug assembly (Figure 24, ①⑧), and tighten the screw plug with a torque of 29-32 Nm.
3. Install the spring seat (Figure 24, ③), the compensator spring (Figure 24, ④) and the limit pin (Figure 24, ⑨).
4. Install the screw plug assembly (Figure 24, ⑤⑥⑦⑧), and tighten the screw plug with a torque of 75-83 Nm.
5. Install the damping plug (Figure 24, ⑫), and tighten it with a torque of 1.7-2.3 Nm.
6. Install the screw plug assembly (Figure 24, ①⑥⑧), and tighten the screw plug with a torque of 29-32 Nm.
7. Install the damping plug (Figure 24, ⑬), and tighten it with a torque of 5.1-5.9 Nm.
8. Install the screw plug assembly (Figure 24, ⑭⑮), and tighten the screw plug with a torque of 12.1-12.4 Nm.
9. Install the screw plug assembly (Figure 24, ⑩⑪), and tighten the screw plug with a torque of 9.8-10.2 Nm.
10. Install three O-rings (Figure 23, ③85).
11. Use four screws (Figure 23, ③85) to fasten the compensator housing to the end cover. Tighten the screws with a torque of 31-37 Nm. When tightening, do it in a crisscross pattern and retighten the first screw.




Figure 24




Figure 25




Figure 26

Ordering code for Industrial Controller Seal Kit (57-141 cc)

Ordering code	Pump displacement [cc/rev]												
	10	13	18	20	45	50	57	63	74	81	98	106	141
9901547-000							•	•	•	•	•	•	•

7.11 Disassembly – Torque Controller/Power Limiter (PVM 57 cc to 141 cc)

1. Remove the oil pipe (Figure 26, 122) and remove it at both ends.
2. Remove the joint (Figure 26, 126) and the joint (Figure 26, 121).
3. Remove the tee (Figure 26, 119), which contains a damping plug (Figure 26, 120).
4. Remove the torque valve (Figure 26, 118).

7.12 Assembly – Torque Controller/Power Limiter (PVM 57 cc to 141 cc)

1. Install the torque control valve (Figure 26, 118). Set the installation height as shown in **Figure 2**. After adjusting the height, tighten the torque control valve with a torque of 40 - 44 Nm.
2. Install the tee (Figure 26, 119), which contains the damping plug (Figure 26, 120). Tighten the tee with a torque of 33-35 Nm.
3. Install the joint (Figure 26, 126) and tighten it with a torque of 14-16 Nm.
4. Install the joint (Figure 26, 121) and tighten it with a torque of 20-22 Nm.
5. Install the oil pipe (Figure 26, 122) and tighten both ends with a torque of 14-16 Nm.




Figure 27

7.13 Disassembly – Auxiliary Mounting Flange (PVM 45 cc to 141 cc)

1. Remove the O-ring (Figure 27, 71).
2. Remove the coupling (Figure 27, 73).
3. Remove the screws (Figure 28, 70) (there are 3 screws for PVM45 and 4 screws for PVM57-141) and take off the series pump flange (Figure 27, 69).
4. Remove the O-ring (Figure 27, 72).

7.14 Assembly – Auxiliary Mounting Flange (PVM 45 cc to 141 cc)

Apply lubricating grease to the O-ring (Figure 27, 72) and then fit it onto the series pump flange (Figure 27, 69).

Install the screws (there are 3 screws for PVM45 and 4 screws for PVM57-141), and fix the series pump flange (Figure 27, 69) to the end cover. Tighten the screws of the PVM45 series with a torque of 63-77 Nm and tighten the screws of the PVM57-141 series with a torque of 103-127 Nm.

Apply lubricating grease to the O-ring (Figure 27, 71) and then put it over the series pump flange (Figure 27, 69).

Insert the coupling (Figure 27, 73).




Figure 28




Figure 29

PVM Code B Service Guide

Item Number	Part Description	Auxiliary mounting code
69	Adaptor	C,D,E,F
70	Screw	C,D,E,F
71	O-Ring	C,D,E,F
72	O-Ring	A, B, C,D,E,F
73	Coupler	A, B, C,D,E,F

Ordering code for Auxiliary mounting kit (10cc to 141 cc)

Code O	Single pump, non-thru-drive
Code A	SAE A, 2-bolt, 9T spline
Code B	SAE A, 2-bolt, 11T spline
Code C	SAE B, 2-/4-bolt, 13T spline
Code D	SAE B-B, 2-/4-bolt, 15T spline
Code E	SAE C, 2-/4-bolt, 14T spline
Code F	SAE C-C, 2-/4-bolt, 17T spline

Ordering Code	Type	Pump Displacement [cc/r]													
		10	13	18	20	45	50	57	63	74	81	98	106	131	141
9901344-000	Code C	○	○	○	○	○	○	●	●	○	○	○	○	○	○
9901344-001	Code D	○	○	○	○	○	○	●	●	○	○	○	○	○	○
9901344-002	Code E	○	○	○	○	○	○	●	●	○	○	○	○	○	○
9901344-003	Code C	○	○	○	○	○	○	○	○	●	●	●	●	○	○
9901344-004	Code D	○	○	○	○	○	○	○	○	●	●	●	●	○	○
9901344-005	Code E	○	○	○	○	○	○	○	○	●	●	●	●	○	○
9901344-006	Code F	○	○	○	○	○	○	○	○	●	●	●	●	○	○
9901344-008	Code C	○	○	○	○	○	○	○	○	○	○	○	○	●	●
9901344-009	Code D	○	○	○	○	○	○	○	○	○	○	○	○	●	●
9901344-010	Code E	○	○	○	○	○	○	○	○	○	○	○	○	●	●
9901344-011	Code F	○	○	○	○	○	○	○	○	○	○	○	○	●	●
9901344-012	Code C	○	○	○	○	●	●	○	○	○	○	○	○	○	○
9901344-013	Code D	○	○	○	○	●	●	○	○	○	○	○	○	○	○
9901344-014	Code A	●	●	●	●	○	○	○	○	○	○	○	○	○	○
9901344-015	Code B	●	●	●	●	○	○	○	○	○	○	○	○	○	○
9901344-016	Code A	○	○	○	○	●	●	○	○	○	○	○	○	○	○
9901344-017	Code B	○	○	○	○	●	●	○	○	○	○	○	○	○	○
9901344-018	Code A	○	○	○	○	○	○	●	●	○	○	○	○	○	○
9901344-019	Code B	○	○	○	○	○	○	●	●	○	○	○	○	○	○
9901344-020	Code A	○	○	○	○	○	○	○	○	●	●	●	●	○	○
9901344-021	Code B	○	○	○	○	○	○	○	○	●	●	●	●	○	○
9901344-022	Code A	○	○	○	○	○	○	○	○	○	○	○	○	●	●
9901344-023	Code B	○	○	○	○	○	○	○	○	○	○	○	○	●	●
9901344-024	Code O	●	●	●	●	●	●	●	●	●	●	●	●	●	●

7.15 Disassembly - Shaft Seal (PVM 10 cc to 141 cc)

1. Use an appropriate circlip plier to remove the circlip 16 inside the front housing.
2. Use a sealing ring hook or a circlip plier to pierce the end face of the shaft seal and remove the shaft seal 15.

7.16 Assembly – Shaft Seal (PVM 10 cc to 141 cc)

1. Check whether there is rust, wear or contamination in the sealing area of the shaft. If necessary, polish the sealing area of the shaft.
2. Lubricate the lip of the new shaft seal with clean hydraulic oil. Install a shaft sleeve on the shaft end to prevent the shaft seal from being damaged during installation.
3. Keep the shaft seal placed perpendicular to the shaft. Press the new shaft seal into the housing, positioning it adjacent to the snap ring groove.
4. Use an appropriate circlip plier to install the circlip.
5. Remove the shaft sleeve.




Figure 30

PVM Code B Service Guide

7.17 Pump Seal Kits

7.17.1 Pump seal Kit 10-13-18-20 cc

Item	Part Number	QTY	Description
14	943990	1	Gasket (Flange)
15	937340	1	Seal, Shaft, FKM
16	101680-162	1	Snap Ring
22-A	115044-008	2	O-Ring
24	937317	1	Gasket (End cover)
25-A	115044-002	1	O-Ring
26-A	115044-004	2	O-Ring
33	104166-221	1	O-Ring
36	197573	1	Back-Up Ring
37	104166-015	1	O-Ring
40	937455	1	Ring, Glide
41	104166-110	1	O-Ring
43	115001-023	1	Back-Up Ring
44	104166-023	1	O-Ring
45	115001-022	1	Back-Up Ring
46	104166-022	1	O-Ring
58	101680-145	1	Snap Ring
72	104166-152	1	O-Ring




Figure 31

7.17.2 Pump seal Kit 45-50 cc

Item	Part Number	QTY	Description
4	107275-017	1	O-Ring
14	932915	1	Gasket (Flange)
15	626933	1	Seal, Shaft
16	101680-175	2	Snap Ring
22-A	115044-010	1	O-Ring
24	932916	1	Gasket (Endcover)
26-A	115044-006	2	O-Ring
33	104166-224	1	O-Ring
36	197573	1	Back-Up Ring
37	104166-015	1	O-Ring
40	932924	1	Ring, Glide
41	104166-210	1	O-Ring
43	4993969-028	1	Back-Up Ring
44	104166-028	1	O-Ring
45	4993969-027	1	Back-Up Ring
46	104166-027	1	O-Ring
71	104166-155	1	O-Ring
72	104166-152	1	O-Ring




Figure 32

7.17.3 Pump seal Kit 57-63 cc

Item	Part Number	QTY	Description
14	934445	1	Gasket (Flange)
15	513439	1	Seal, Shaft, FKM
16	101680-200	2	Snap Ring
22-A	115044-010	1	O-Ring
24	934444	1	Gasket (Endcover)
26-A	115044-006	2	O-Ring
33	104166-134	1	O-Ring
36	12113634	1	Back-Up Ring
37	104166-015	1	O-Ring
40	934489	1	Ring, Glide
41	104166-211	1	O-Ring
43	4993969-127	1	Back-Up Ring
44	104166-127	1	O-Ring
45	4993969-126	1	Back-Up Ring
46	104166-126	1	O-Ring
71	104166-155	1	O-Ring, Adapter, SAE-B Thru-drive Port
71*	104166-159		O-Ring, Adapter, SAE-C Thru-drive Port
72	104166-152	1	O-Ring
130-A	104166-914		O-Ring




Figure 33

7.14.4 Pump seal Kit 74-81 cc

Item	Part Number	QTY	Description
14	943362	1	Gasket (Flange)
15	6047773-001	1	Seal, Shaft, FKM, High Pressure
16	101680-225	1	Snap Ring
22-A	115044-012	2	O-Ring
24	943361	1	Gasket (Endcover)
26-A	115044-006	2	O-Ring
33	104166-138	1	O-Ring
36	197573	1	Back-Up Ring
37	104166-015	1	O-Ring
40	943367	1	Ring, Glide
41	104166-118	1	O-Ring
43	4993969-131	1	Back-Up Ring
44	104166-131	1	O-Ring
45	4993969-129	1	Back-Up Ring
46	104166-129	1	O-Ring
71	104166-155	1	O-Ring, Adapter, SAE-B Thru-drive Port
71*	104166-159		O-Ring, Adapter, SAE-C Thru-drive Port
72	104166-152	1	O-Ring
130-A	104166-914		O-Ring




Figure 34

PVM Code B Service Guide

7.14.5 Pump seal Kit 98-106 cc

Item	Part Number	QTY	Description
14	943212	1	Gasket (Flange)
15	6047773-001	1	Seal, Shaft, FKM, High Pressure
16	101680-225	1	Snap Ring
22-A	115044-016	2	O-Ring
24	943211	1	Gasket (Endcover)
26-A	115044-006	2	O-Ring
33	104166-138	1	O-Ring
36	197573	1	Back-Up Ring
37	104166-015	1	O-Ring
40	943367	1	Ring, Glide
41	104166-118	1	O-Ring
43	4993969-131	1	Back-Up Ring
44	104166-131	1	O-Ring
45	4993969-129	1	Back-Up Ring
46	104166-129	1	O-Ring
71	104166-155	1	O-Ring, Adapter, SAE-B Thru-drive Port
71*	104166-159		O-Ring, Adapter, SAE-C Thru-drive Port
72	104166-152	1	O-Ring
130-A	104166-914		O-Ring




Figure 35

7.14.6 Pump seal Kit 131-141 cc

Item	Part Number	QTY	Description
14	933088	1	Gasket (Flange)
15	6047774-001	1	Seal, Shaft, FKM, High Pressure
16	115019-250	1	Snap Ring
22-A	115044-016	2	O-Ring
24	933087	1	Gasket (Endcover)
26-A	115044-006	2	O-Ring
33	104166-229	1	O-Ring
36	197593	1	Back-Up Ring
37	104166-116	1	O-Ring
40	933078	1	Ring, Glide
41	104166-123	1	O-Ring
43	4993969-033	1	Back-Up Ring
44	104166-033	1	O-Ring
45	4993969-032	1	Back-Up Ring
46	104166-032	1	O-Ring
71	104166-155	1	O-Ring, Adapter, SAE-B Thru-drive Port
71*	104166-159		O-Ring, Adapter, SAE-C Thru-drive Port
72	104166-152	1	O-Ring
130-A	104166-914		O-Ring




Figure 36

8. Troubleshooting for common faults

8.1 Excessive noise and/or vibration

Item	Description	Action
Check fluid level in reservoir.	Insufficient hydraulic fluid causes cavitation.	Fill the reservoir to proper level.
Check for air in system.	Air in system causes noisy, erratic control.	Purge air and tighten fittings. Check inlet for leaks.
Check pump inlet pressure/vacuum.	Improper inlet conditions cause erratic behaviour and low output flow.	Correct pump inlet pressure/vacuum conditions. Refer to the Hydraulic Parameters topic.
Inspect shaft couplings.	A loose or incorrect shaft coupling causes excessive noise and/or vibration.	Repair or replace coupling and ensure that correct coupling is used.
Check shaft alignment.	Misaligned shafts create excessive noise and/or vibration.	Correct shaft misalignment.

8.2 Actuator response is sluggish

Item	Description	Action
Check external system relief valve setting.	Low external relief valve setting slows down system.	Adjust external relief valve setting following manufacturer's recommendations. External relief setting must be above PC setting to operate properly.
Check PC and LS control setting.	Low PC setting prevents the pump from achieving full stroke. Low LS setting limits output flow.	Adjust PC and LS setting. Refer to the
Adjustments chapter.		
Check LS control signal pressures.	Incorrect LS signal will not allow pump to operate correctly.	Inspect system to ensure that proper LS signal transmit to pump.
Internal system leaks.	Misaligned shafts create excessive noise and/or vibration.	Refer to Authorized Service Center for required repair.
Hydraulic fluid viscosity above acceptable limits.	Hydraulic fluid viscosity above acceptable limits or low fluid temperature will not allow the pump to fill or control to operate properly.	Allow system to warm up before operation or use fluid with the appropriate viscosity grade for expected operating temperatures.
Check external system valving.	Malfunctioning valving may not allow system to respond properly.	Repair or replace system valving as required.
Check pump case pressure.	High case pressure causes the system to be sluggish.	Correct case drain line restrictions.

8.3 System operating hot

Item	Description	Action
Check fluid level in reservoir.	Insufficient volume of hydraulic fluid will not meet cooling demands of system.	Fill reservoir to proper level. Verify proper size of reservoir.
Hydraulic fluid viscosity above acceptable limits.	Fluid viscosity above acceptable limits or low fluid temperature will not allow the pump to fill or control to operate properly.	Allow system to warm up before operation or use fluid with the appropriate viscosity grade for expected operating temperatures.
Check external system relief valve setting.	Fluid passing through relief valve adds heat to system.	Adjust external system relief valve setting following manufacturer's recommendations. External relief valve setting must be above PC setting for proper operation.

Item	Description	Action
Check PC and LS control setting.	Low PC setting will prevent the pump from achieving full stroke. Low LS setting will limit output flow.	Adjust PC and LS setting.
Check pump inlet pressure/vacuum.	High inlet vacuum adds heat to system.	Correct inlet pressure/vacuum conditions.
Check input speed.	Low input speeds decrease flow.	Adjust input speed.
Check pump rotation.	Incorrect rotational configuration will cause low flow.	Use pump with appropriate rotational configuration.

8.4 Low pump output flow

Item	Description	Action
Check fluid level in reservoir.	Insufficient hydraulic fluid will limit output flow and cause internal damage to pump.	Fill the reservoir to proper level.
Hydraulic fluid viscosity above acceptable limits.	Fluid viscosity above acceptable limits or low fluid temperature will not allow the pump to fill or control to operate properly.	Allow system to warm up before operating or use fluid with the appropriate viscosity grade for expected operating temperatures.
Check external system relief valve setting.	External relief valve set below PC setting causes low output flow.	Adjust external relief valve following manufacturer's recommendation. External relief valve setting must be above PC setting to operate properly.
Check PC and LS control setting.	Low PC setting prevents the pump from achieving full stroke.	Adjust PC and LS setting. Refer to the Adjustments chapter.
Check pump inlet pressure/vacuum.	High inlet vacuum causes low output flow.	Correct inlet pressure conditions.
Check input speed.	Low input speeds decrease flow.	Adjust input speed.
Check pump rotation.	Incorrect rotational configuration causes low flow.	Use pump with appropriate rotational configuration.

8.5 Pressure or flow instability

Item	Description	Action
Check for air in system.	Air in system causes erratic operation.	Activate PC allowing system to bleed air. Check inlet line for leaks and eliminate source of air ingress.
Check control spools.	Sticking control spools cause erratic operation.	Inspect spools for free movement in bore. Clean or replace.
Check LS setting.	Low LS setting may cause instability.	Adjust LS setting to proper level. See the Adjustments chapter.
Check LS signal line.	Blocked LS signal line interferes with proper LS operation.	Remove blockage.
Check external relief valve and PC setting.	Insufficient pressure differential between PC setting and external relief valve.	Adjust external relief valve or PC control settings to appropriate level. Relief valve setting must be above PC setting to operate properly.
Check external relief valve.	Chattering external relief valve may cause unstable feedback to pump control.	Adjust or replace relief valve.

8.6 System pressure not reaching PC setting

Item	Description	Action
Check PC control setting.	System pressure will not rise above PC setting.	Adjust PC to appropriate setting. Refer to the Adjustments chapter.
Check external relief valve.	External relief valve setting below PC setting presents pressure compensation.	Adjust external relief valve according to manufacturer's recommendations. External relief valve must be set above PC setting to operate properly.
Inspect PC control spring.	Broken, damaged, or missing spring will cause erratic operation.	Replace the spring as required.
Inspect PC spool for wear.	Wear of PC spool causes internal leakage in the control.	Replace the spool as required.
Inspect PC spool for proper orientation.	Improper orientation results in poor operation.	Correct orientation of spool.
Check PC control for contamination.	Contamination may interfere with movement of the PC spool.	Clean PC control components, take appropriate action to eliminate contamination.

8.7 High inlet vacuum

Item	Description	Action
Check fluid temperature.	Low temperature increases viscosity. High fluid viscosity causes high inlet vacuum.	Allow system to warm up before operating.
Inspect inlet screen.	Blocked or restricted inlet screen causes high inlet vacuum.	Clean screen/remove blockage.
Check inlet piping.	Too many fittings, bends, or long piping causes high inlet vacuum.	Eliminate fittings to make path more direct.
Hydraulic fluid viscosity above acceptable limits.	High fluid viscosity causes high inlet vacuum.	Select fluid with appropriate viscosity for expected operating temperature.

Cartridge valves

- DCV directional control valves
- Electric converters
- Electric machines
- Electric motors
- Fluid Conveyance
- Gear motors
- Gear pumps
- Hydraulic integrated circuits (HICs)
- Hydrostatic motors
- Hydrostatic pumps
- Industrial hydraulics
- Orbital motors
- PLUS+1® controllers
- PLUS+1® displays
- PLUS+1® joysticks and pedals
- PLUS+1® operator interfaces
- PLUS+1® sensors
- PLUS+1® software
- PLUS+1® software services, support and training
- Position controls and sensors
- PVG proportional valves
- Steering components and systems
- Telematics

Danfoss Power Solutions is a global manufacturer and supplier of high-quality hydraulic and electric components. We specialize in providing state-of-the-art technology and solutions that excel in the harsh operating conditions of the mobile off-highway and industrial markets as well as the marine sector. Building on our extensive applications expertise, we work closely with you to ensure exceptional performance for a broad range of applications. We help you and other customers around the world speed up system development, reduce costs and bring vehicles and vessels to market faster.

Danfoss Power Solutions – your strongest partner in hydraulics and mobile

Go to www.danfoss.com for further product information.

We offer you expert worldwide support for ensuring the best possible solutions for outstanding performance. And with an extensive network of Global Service Partners, we also provide you with comprehensive global service for all of our components.

Local address:

Hydro-Gear

www.hydro-gear.com

Daikin-Sauer-Danfoss

www.daikin-sauer-danfoss.com

Danfoss

Power Solutions (US) Company

2800 East 13th Street
Ames, IA 50010, USA
Phone: +1 515 239 6000

Danfoss

Power Solutions GmbH & Co. OHG

Krokamp 35
D-24539 Neumünster, Germany
Phone: +49 4321 871 0

Danfoss

Power Solutions ApS

Nordborgvej 81
DK-6430 Nordborg, Denmark
Phone: +45 7488 2222

Danfoss

Power Solutions Trading (Shanghai) Co., Ltd.

Building #22, No. 1000 Jin Hai Rd Jin Qiao,
Pudong New District Shanghai, China 201206
Phone: +86 21 2080 6201

Danfoss can accept no responsibility for possible errors in catalogues, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without subsequent changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.